

# MARINE DELIVERY CHECK LIST

PRE-DELIVERY INSPECTION AND FINAL DELIVERY										
DEALER:	ALER:					CUSTOMER:				
Dealer's Name		Phone Number		Dealer No.		Customer's Name		Phone Number		
Address		City		Province	Postal Code	Address		City	Province	Postal Code
Outboard Model/Type	Outboard Motor Se	rial No.	Engine N	lo.		Boat Brand	Boat Model	Max. HP Rating	Boat Length	

Please check the box for each item you have verified as correct. Refer to the Set-Up Instructions, Shop Manuals and Rigging Guide. Follow those specific procedures in detail.

### SET UP

#### PRE-INSTALLATION, EXTERNAL APPEARANCE

- Check for paint scratches.
- Check for paint defects.

#### □ INSTALLATION

- Correct installation location, height.
- Check motor mount bolt torque.
- Check sealant applied to mount bolt holes.

#### STEERING SYSTEM

• Check for smooth operation, making sure the motor does not interfere with the control cables, steering cable and/or link arm, wire harness etc. when the steering wheel is turned fully left or right.

#### ENGINE OIL

Check engine oil level.

#### GEAR OIL

 Check for proper gear oil level. Make sure the level and drain plugs are tight. Use gear oil with the correct API service classification

#### □ ALL NUT, BOLTS & OTHER FASTENERS

• Check and tighten as necessary.

## ELECTRICAL SYSTEM/GAUGES

- Check all connections.
- Battery is fully charged and polarity correct.
- Make sure meters, indicators and switches are correctly connected.

#### □ REMOTE/TILLER CONTROL SYSTEM

- Make sure the control lever selects forward, neutral and reverse gears.
- Check for full throttle capability and for smooth operation over the range of motion.

#### FUEL SYSTEM

- Be sure the fuel lines are connected securely.
- Check for fuel leaks. If necessary, repair immediately.

#### TILT MECHANISM

- Operate the Power trim/ tilt switch on the motor and at the remote, ensure tilt operation smooth.
- Check the trim meter functions.
- Operate the steering with motor in the up position; make sure nothing interferes with the motor.
- Make sure the tilt stopper locks at full up.
- Check power tilt oil level, motor locked at full up.

## WATER TRIALS OPERATIONAL CHECK LIST

#### OUTBOARD MOTOR INSTALLATION

- Check that there are no leaks from mountings.
- Check boat for balanced weight distribution.
- Check that the exhaust port is 125mm above the water line with the boat at rest.

#### OUTBOARD MOTOR OPERATION

- Check operation of choke and neutral switches.
- Check cooling water comes out the telltale port.
- Check motor operation at trolling speed.
- Check water does not overflow the transom.

# Check for leaks from fuel lines and/or connections.

- Check for water leaks.
- Check for exhaust or oil leaks.

#### PROPELLER SELECTION

- Check engine RPM. At full throttle the engine should reach maximum recommended RPM. Do not operate at full throttle for more than 2 minutes at a time.
- Make sure the propeller does not ventilate at full throttle when trimmed out.

Prop Brand	Prop Model	Prop Size	Max. Engine RPM

### AFTER WATER TRIALS

CHECK & CLEAN THE OUTBOARD MOTOR

CHECK NO WATER IN THE GEAR OIL

☐ FLUSH MOTOR AFTER USING IN SALT OR TURBID ☐ NO FUEL, OIL OR WATER LEAKS WATER

### **CUSTOMER DELIVERY CHECK LIST**

Inspected the unit and verified it is in proper operating condition.	Reviewed Warranty Coverage Terms and Conditions.	Explained maintenance intervals.	Explained safety precautions.	Customer Signature:	
Reviewed Owner's Manual.	Completed Product Registration form.	Explained boat and motor operation.			
I have received the following:	-		Date:	Dealership Signature:	
Owner's Manual	Warranty Policy	Copy of Product Registration Form			

A dealer representative has reviewed the operation of this unit, and the above check lists with me. I have reviewed and understood the warranty policy. I have visually inspected the unit and found no defects.